


## Patient Remote PD108-421

For use with all digital TV's



- 1. POWER button**  
Turns the TV on or off.
- 2. MUTE button**  
Turns the sound on or off.
- 3. TV/AV button**  
Selects enabled external inputs.
- 4. TV/FM button**  
Switches between TV and FM Radio sources.
- 5. SLEEP button**  
Sets the sleep timer. Increments of 10 minutes; up to 120
- 6. LAST button**  
Return to previously viewed channel.
- 7. VOL ◀▶ buttons**  
Decreases or increases the volume.
- 8. OK button**  
Confirms the current channel selection.
- 9. CH ▲ ▼ buttons**  
Selects next or previous channel.
- 10. ARC button**  
Changes the aspect ratio. Repeatedly press the ARC button to select your desired picture format. (See page 41 for instructions on adjusting picture up or down.)
- 11. CC button**  
Cycles through Closed caption choices.
- 12. SAP button**  
Adjust audio mode: MTS-Stereo, Mono, or SAP.
- 13. Number buttons**  
Use to directly enter channels. 0-9
- 14. DASH button**  
Use to enter second part of a digital channel
- 15. CODE button**  
The remote offers independent Bed A or Bed B selectable codes and independent control of a single TV in a two TV room. Insert a paperclip in this hole to select Bed A or Bed B.